Merrymaker

Let's get started.

About five minutes, and you only do it once.

Your caroling bells	This Merrymaker	Your phone	Your Wi-Fi password
With the song cartridge slot	And its power adapter	iPhone or Android, no app	For a 2.4 GHz network

1 Swap the cartridge

Unplug your bells. Press your thumb firmly on **PUSH**, on the back of the control box, and slide the cover off.

Swap the old cartridge for the Merrymaker, pushed in until it's snug. Keep the old one safe.



Press, then slide


Merrymaker in place

2 Plug in and turn on

Use the adapter that came with Merrymaker, since it needs a little more power than the old one. Then switch your bells on. The red **PWR** light comes on, and after a few seconds the blue **NET** light starts blinking.

3 Join the Merrymaker network

In your phone's Wi-Fi settings, tap the network called **Merrymaker-** followed by four letters or numbers. There's no password.

A Merrymaker page opens by itself. If it doesn't, go to **`192.168.4.1`** in your browser. Read the terms of use and tap **Agree**. If your phone warns there's no internet, stay connected.

4 Choose your home Wi-Fi

Pick your network, type its password and tap **Join network**. The blue NET light stops blinking and stays solid, and the page says **All set**.

Save your bells' address

Tap **Copy address**, then **Finish**. Back on home Wi-Fi, paste it into Safari or Chrome and add the page to your home screen.

Yours: **`merrymaker-`** `----------` **`.local`** the four characters from step 3

5 Pick a song

Tap a collection, tap a song, and let them ring. More than one set? Set each one up on the same Wi-Fi, and they all ring together.

Lights, buttons and help on the back

merrymakerbells.com/setup

Lights and buttons

NET light

Blue · Wi-Fi

Blinking
The Merrymaker network is open for your phone to join.

On
On your home Wi-Fi and ready to play.

PWR light

Red · On whenever Merrymaker has power

STS light

Green · Status

Flickering
Ringing the bells. It flashes with every note.

WIFI button

For finding or moving your set

Press
Opens the Merrymaker network again, keeping your Wi-Fi. Join it to see your set's address or move it to another network. Closes after 5 minutes.

Hold 5 seconds
Forgets your Wi-Fi and starts setup again.

RST button

For playing without your phone

Press
Plays or stops a song.

Hold 5 seconds, then let go
Forgets your Wi-Fi.

Hold 10 seconds
Resets everything: blue and green flash in turn to confirm. Start again at step 3.

If something's not right

- **No Merrymaker network?** If the blue NET light is steady, you're already set up: press WIFI to open it again. No red PWR light? Check the bells are on, the adapter is plugged in and the Merrymaker is pushed fully in.
- **Home network not listed?** Merrymaker uses 2.4 GHz Wi-Fi. Choose the network that doesn't end in "5G", or move the bells closer to the router.
- **Couldn't join?** The password was probably mistyped. The Merrymaker network comes back after about 20 seconds; join it and try again.
- **Lost the address, or it won't open?** Press WIFI and join the Merrymaker network: the page shows it again, with a number address like **`192.168.1.42`** to try. Use home Wi-Fi, not mobile data.
- **Bells quiet or missing notes?** Use the included adapter. Test each one under **Bells**.

More at our website

Scan the code for the full setup guide, with photos.

- ♪ Step-by-step setup and more fixes
- ♪ The songbook: every carol on your set
- ♪ Playing several sets together
- ♪ Writing your own songs

merrymakerbells.com

SCAN FOR SETUP

Still stuck? Message us through eBay and we'll help you get ringing. Keep your old song cartridge: you can swap it back any time.

Merrymaker is an independent product, not made by or affiliated with the makers of Ye Merrie Minstrel. "Ye Merrie Minstrel" is used only to describe compatibility. Bells not included.